



#84-06160

# Strip-IT<sup>®</sup>

## GREENHOUSE INDUSTRIAL CLEANER

*Greenhouse Structures and Irrigation Systems /  
Sunblock Wash*

*Removes Heat-set Grease / Oil / Organic Sludge Deposits in Irrigation Lines / Salt /  
Dust Deposits and Common Whitewash Sunblock Coatings / Water Storage Tanks*

**5** gal /  
**20** L  
Net Volume





# Strip-IT®

## GREENHOUSE INDUSTRIAL CLEANER

### DIRECTIONS FOR USE

#### THIS PRODUCT IS A CONCENTRATE AND MUST BE DILUTED BEFORE USING

This product is a specifically formulated combination of sulfuric acid and wetting agents that is recommended for end-of-season cleaning of structures to create a healthy, sanitary environment for new crops being established.

#### GREENHOUSES / NURSERIES, BOTANICAL GARDENS, ATRIUMS, PACKING HOUSES, BOUQUET MANUFACTURERS

**NOTE: All plants and delicate material must be removed from treated area prior to cleaning or removing whitewash from structures. Any contact with plants or other delicate surfaces could cause damage. Recommend wearing safety glasses or goggles and protective clothing while applying STRIP-IT®.**

When making solution, add slowly to surface of solution to avoid splattering. Solution might etch glass or damage surface if allowed to dry.

#### EXTERIOR / INTERIOR STRUCTURES (GREENHOUSES, STORAGE BUILDINGS, ETC.)

Remove all plants and delicate materials prior to cleaning. Spray, mop or brush surfaces with a solution of Floralife STRIP-IT®. When cleaning large areas, use large volume sprayer or pressure washer to apply Floralife STRIP-IT® solution. **Thoroughly wet surface to be cleaned so that all areas are 100% covered. Do not allow solution to dry. Reapply to maintain wetness. (Solution could etch glass or damage surface if allowed to dry.) Let stand 3 to 5 minutes. Rinse all treated areas thoroughly with clean water.**

#### WORK AREA, BENCHES, COOLERS, CONCRETE / GRAVEL FLOORS / SHIPPING PADS, FLOOD FLOORS

Follow interior structures cleaning directions. Apply to the underside of benches / equipment and areas subjected to continuous moisture to ensure complete cleaning. For lightly soiled areas use a mop or brush to apply. Allow to soak for 3 - 5 minutes. Rinse all treated areas thoroughly with clean water.

#### IRRIGATION LINES / DITCHES AND STORAGE TANKS

Use this procedure only when irrigation system or storage water areas are isolated from the crop. Direct contact of Floralife STRIP-IT® with plant material will cause phytotoxicity and possible loss of plants. It is important to prepare a solution of Floralife STRIP-IT® by using exact recommended rates for irrigation lines and storage tanks for safe removal of algae and salt deposits.

Fill irrigation lines or add the solution directly to water in the storage tank and allow solution to sit for 8 - 12 hours. Flush system with clean water until there is no visible soap foam at the farthest end of the line. If dosing Floralife STRIP-IT® into the lines, use a higher recommended dilution and let sit for 1 - 2 hours only, then flush system with clean water. Storage water lines should be drained and rinsed. Remove any large debris prior to filling with fresh water.

#### WHITEWASH SUN BLOCK COATING REMOVAL

Use large volume sprayer or pressure washer to apply Floralife STRIP-IT® solution for whitewash removal. Thoroughly wet surface to be cleaned or stripped with the Floralife STRIP-IT® solution so that all areas are 100% covered.

Allow the solution to remain wet on the surface for 3 - 5 minutes. Do not allow solution to dry. Reapply to maintain wetness. (Solution could etch glass or damage surface if allowed to dry.)

Use a pressure washer or high pressure hose for easy rinsing and removal of whitewash. Use plenty of clean water to remove all traces of the Floralife STRIP-IT® solution.

#### APPLICATION METHODS

High-pressure sprayers or pressure washers are recommended for removal of deposits and whitewash, and for rinsing. Low-pressure sprayer, mop, or brush can be used for lightly soiled areas. Follow recommended use directions. Safe to use on structures, floors, benches, coolers and equipment composed of materials such as aluminum, copper, galvanized steel, plastics, polycarbonate, fiberglass and concrete. DO NOT allow use of Floralife STRIP-IT® to dry on aluminum, tin, galvanized iron, glass, etc. or etching could occur. Rinse thoroughly.

## For greenhouse structures and irrigation systems / water storage tanks and sun block wash

Dissolves and removes heat-set grease / oil / dust deposits / whitewash sun block coatings / salt / algae deposits

### FLORALIFE STRIP-IT® DILUTION TABLE

Areas of use	Dilution Rates (fl. oz. Floralife Strip-It® / 1 gallon water)
Exterior structures, including pipes and drains	6.5 - 13.0 fl. oz.
Interior structures, including floors, benches coolers, pipes and equipment	4.0 - 5.0 fl. oz.
Greenhouse whitewash removal	10.0 - 13.0 fl. oz.
Cleaning irrigation lines	1.5 - 3.0* fl. oz.
Storage tanks	1.5 - 2.5 fl. oz.

\*higher dilution for dose application only

### Floralife STRIP-IT®



## Danger

Harmful if swallowed. Causes severe skin burns and eye damage.

Do not breathe mist or vapor. Wash thoroughly after handling. Do not eat, drink or smoke when using this product. Wear protective gloves/protective clothing/eye protection/face protection. Response if swallowed: Rinse mouth. Do NOT induce vomiting. If on skin (or hair): Take off immediately all contaminated clothing. Rinse skin with water/shower. If inhaled: Remove person to fresh air and keep comfortable for breathing. If in eyes: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. Immediately call a poison center/doctor. Wash contaminated clothing before reuse. Store locked up. Dispose of contents/container in accordance with local/regional/national/international regulations.



Floralife, a division of Smithers-Oasis Company  
751 Thunderbolt Drive | Walterboro, SC  
Made in the U.S.A. | [www.floralife.com](http://www.floralife.com)

For professional use only.



HDPE



0 73095106160 7